

SONY®





PS VITA™

PlayStation®Vita

In-ear headset Instruction Manual

PCH-ZHS1 E

A**B**

Precautions

Before using this product, carefully read this manual and retain it for future reference. Read also the instructions for the PlayStation®Vita system.

Safety

- Do not use this product while driving a car, riding a bicycle or engaging in any activity that requires your complete attention. Doing so may result in accidents or injury.
- Keep this product out of the reach of small children. Children may swallow small parts, which can lead to injury.

Use and handling

- If this product causes discomfort to your ears, immediately discontinue use.
- Do not expose this product to high temperatures, high humidity or direct sunlight.
- Do not allow the product to come into contact with any liquids.
- Do not place any objects on top of the product.
- Do not twist the cable or pull it forcibly.
- Do not throw or drop this product, or otherwise expose it to strong physical impact.
- Never disassemble or modify the product.
- Follow the instructions below to help prevent the product exterior from deteriorating or becoming discoloured.
 - Wipe with a soft, dry cloth.
 - Do not place any rubber or vinyl materials on the product exterior for an extended period of time.
 - Do not use solvents or other chemicals. Do not wipe with a chemically-treated cleaning cloth.
- To clean the earpieces, disconnect them from the headphones and wash them by hand, using a mild soap. After cleaning, dry the earpieces thoroughly before using them.

Changing the earpieces

The headset is equipped with medium-size earpieces. If the earpieces do not fit your ears, replace them with the included small or large-size earpieces. Twist and pull the earpieces to remove them (Figure **A**).

Hint

When installing the earpieces, attach them firmly so that they do not come loose during use.

How to use the in-ear headset

Connect the in-ear headset to the PS Vita system as shown in Figure **B**. When you are not using the microphone, put the MIC MUTE in the ON position.

Hint

For information about using the microphone with software, refer to the instructions supplied with the software.

Specifications

Cord	1.2 m
Plug	4-pole gold-plated mini plug
Weight	Approx. 15 g (including cord)
Operating environmental temperature	5°C - 35°C

Microphone	Type	Electret condenser type
	Directional characteristics	Omnidirectional
	Input sensitivity	-42 dB (0 dB = 1 V/Pa)

Headphones	Type	Dynamic style
	Driver unit	10 mm diameter
	Maximum power input	60 mW*
	Impedance	16 Ω
	Sensitivity	99 dB/mW
	Frequency response	20 Hz-20 kHz

* This is the measured value based on the IEC (International Electrotechnical Commission) standard.

Design and specifications are subject to change without notice.

GUARANTEE

This product is covered for 12 months from date of purchase by the manufacturer's warranty. Please refer to the guarantee supplied in the PS Vita package for full details.

The manufacturer of this product is Sony Computer Entertainment Inc., 1-7-1 Konan, Minato-ku, Tokyo 108-0075 Japan.

The Authorised Representative for EMC and product safety in Europe is Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany.

Distributed in Europe by Sony Computer Entertainment Europe Ltd, 10 Great Marlborough Street, London, W1F 7LP, United Kingdom.


This product may fall within the scope of national export control legislation. You must comply fully with the requirements of such legislation and of all other applicable laws of any jurisdiction in relation to this product.



Where you see this symbol on any of our electrical products or packaging, it indicates that the relevant electrical product should not be disposed of as general household waste in Europe. To ensure the correct waste treatment of the product, please dispose of it in accordance with any applicable local laws or requirements for disposal of electrical equipment. In so doing, you will help to conserve natural resources and improve standards of environmental protection in treatment and disposal of electrical waste.

“PS” and “PlayStation” are registered trademarks of Sony Computer Entertainment Inc.

“PS VITA” is a trademark of the same company.

“SONY” and “” are registered trademarks of Sony Corporation.



© 2012 Sony Computer Entertainment Europe. All rights reserved.