

SONY®



PS VITA™

PlayStation®Vita

Pouch Instruction Manual

PCH-ZSP1

Compatible hardware: PlayStation®Vita system

Carefully read the information on this package together with the instructions for your hardware before using this product.


Precautions

Turn off the power or put the PS Vita system in standby mode before inserting the PS Vita system into the pouch. Otherwise, it can overheat and damage the system.

Use and handling

For use only with the PS Vita system.

The PS Vita system can be stored with headset or headphones attached.



Headset and Headphones are sold separately

How to clean the pouch

- To clean the pouch, soak a soft cloth in water and a small amount of detergent, and then squeeze off excess. Use the cloth to carefully wipe off dirt. Do not dry the pouch in direct sunlight.
- Do not use solvents or other chemicals. Do not wipe with a chemically-treated cleaning cloth.

Design and specifications are subject to change without notice.


The manufacturer of this product is Sony Computer Entertainment Inc., 1-7-1 Konan, Minato-ku, Tokyo 108-0075 Japan.

Distributed in Europe by Sony Computer Entertainment Europe Ltd, 10 Great Marlborough Street, London, W1F 7LP, United Kingdom.

Limitations of Liability

Other than as expressly set forth by Sony Computer Entertainment Europe Limited (“SCEE”) or any other Sony entity, or their suppliers or authorised service facilities, except to the extent prohibited by applicable laws, SCEE or any other Sony entity, or their suppliers or authorised service facilities, shall not be liable for any damages, including special, incidental or consequential damages, or fees arising out of the use or inability to use this product.

“PS” and “PlayStation” are registered trademarks of Sony Computer Entertainment Inc. “PSVITA” is a trademark of the same company.

“SONY” and “” are registered trademarks of Sony Corporation.



eu.playstation.com/psvita