

Wireless networking feature

When using the scan function to select a wireless LAN access point, access points that are not intended for public use may be displayed. Only connect to an access point that you are authorized to use.

Charging notices

- Charge in an environment where the temperature range is between 10 °C and 30 °C (50 °F and 86 °F). Charging may not be as effective when performed in other environments.
- The battery has a limited lifespan. Battery duration will gradually decrease with repeated usage and age. Battery life also varies depending on the storage method, usage state, environment, and other factors.
- When the product is not used for an extended period of time, it is recommended that you fully charge it at least once a year in order to maintain battery functionality.

Screen

- Do not press your finger on the screen with excessive force. Also, do not scrape or scratch the screen with anything hard, such as metal, or anything with a sharp tip (such as a pencil or your fingernails). Any of these actions may damage or break the screen.
- Do not place the product screen-side down, as this may cause damage to the screen and sticks.
- Prolonged contact with water or dust may damage the screen and shorten its life.
- Direct exposure to sunlight may damage the product’s screen. Be careful when using the product outdoors or near a window.
- A small number of pixel display defects may be present and considered normal.
- When using the product in a cold environment, you may notice shadows on the graphics or the screen may appear darker than usual. This is not a malfunction, and the screen will return to normal when the temperature goes up.

Care and cleaning

Follow the precautions below to help prevent the product exterior from deteriorating or discoloring.

- Do not allow rubber or vinyl materials to be in prolonged contact with the product.
- Do not use thinner, benzene, or alcohol. Avoid using wipes, chemical cloths, and other products that contain such substances.


End of life product recycling

The product is made of many materials that may be recycled and contains a lithium-ion battery. Follow local regulations when disposing of the product. Sony products can be recycled for free in the United States and Canada by dropping the product off at a number of nationwide locations. Visit www.sony.com/ecotrader for details.

Charge the product

Connect to your PS5® console using the included USB cable when your console is turned on or in rest mode.

Once charging begins, the product’s charging status momentarily displays on the screen.



- To charge the product while in rest mode, you have to configure the settings. From the PS5 home screen, select **Settings > System > Power Saving > Features Available in Rest Mode > Supply Power to USB Ports**, and then select a setting other than **Off**.
- Use the USB cable provided with this product or with your PS5 console. When using other cables, be sure to use a USB cable that complies with USB standards. Not all USB cables will function properly.
- You can also charge the product by connecting the USB cable to a AC adapter that supports USB PD (power delivery). Please use an AC adapter with USB Type-C® that outputs at least 5 V/3 A. You might not be able to charge the product on some devices.

Specifications

Design and specifications are subject to change without notice. The operating instructions may vary depending on the system software version in use with your PS5 console and the product.

Screen	8-inch Full HD LCD touchscreen
Input/output	USB port Headset jack
Sound	Built-in stereo speakers
Networking	IEEE 802.11 a/b/g/n/ac PlayStation Link™ (2.4 GHz)
Charge time	Approx. 2 hours 30 minutes*
Electrical rating	5 V $\overline{\text{---}}$ 3 A
Battery type	Built-in lithium-ion battery
Battery voltage	3.87 V $\overline{\text{---}}$
Battery capacity	4,370 mAh
Mass	Approx. 529 g (18.7 oz)
Operating temperature	5 °C to 35 °C (41 °F to 95 °F)

* This time is estimated based upon charging via the PS5 console’s USB Type-C port.

Included USB cable

Company: SONY / Part No.: 1-018-350-**, 1-018-351-**

* represents a number between 0 and 9.

System software

- The system software of the product are licensed to you under the terms of a separate end user license agreement. For details, visit playstation.com/legal/product-ssla/.
- Always update the system software of your PS5 console and the product to the latest version.

Remote Player Lecteur à distance

Instruction Manual / Mode d'emploi



CFI-Y1001

HQ622010021H0

⚠️ Precautions

Player comfort

If you experience any of the following health problems, discontinue use of the product immediately. If symptoms persist, consult a doctor.

- Dizziness, nausea, fatigue or symptoms similar to motion sickness
- Discomfort or pain in a part of the body, such as eyes, ears, hands or arms

Vibration function

- If the product is sitting on a flat surface, the vibration of the product during gameplay may cause it to fall, leading to injury or malfunction.
- Do not use the vibration or trigger effect function if you have any ailment or injury to body parts such as the bones, joints, or muscles of the hand or arm that may be affected by this vibration function. To enable or disable these features, from the home screen, select **Quick Menu > Settings > Controller**.

Static shock

When using a headset or headphones in particularly dry air conditions, you may sometimes experience a small and quick (static) shock on your ears. This is a result of static electricity accumulated in the body, and is not a malfunction of your headset or headphones.

Motion sensor

When using the motion sensor function of the product, be cautious of the following points. If the product hits a person or object, it may cause accidental injury or damage.

- Before using the motion sensor function, make sure you have enough space to move around.
- Firmly grip the product to prevent it from slipping out of your grasp and causing damage or injury.
- If using a product that is connected to the PlayStation®5 console with a USB cable, make sure there is enough space for the cable so that the cable will not hit a person or object.

Light bar

Do not stare at the light bar on the product when it is blinking. Stop using the product immediately if you experience any discomfort or pain.

Set up and handling

- Always ensure the product, accessories, or its connectors are free of liquid, excess dust and small particles.
- Do not touch the connectors or insert anything into the product.
- Do not use the product, cables, or connectors if they are damaged or modified.
- Do not leave the product or accessories on the floor or in a place where it may cause someone to trip or stumble.
- Do not place the product or accessories on surfaces that are unstable, tilted, or subject to vibration.
- Do not place heavy items on the product, or cables, throw or drop the product, or otherwise expose it to strong physical impact.
- Do not look at the screen or attempt to use the product while walking, driving or riding a bicycle as doing so could result in an accident and/or injury.
- Do not touch the product during an electrical storm when it is charging.
- Do not touch any other devices connected to the product with wet hands. Doing so may cause an electrical shock.
- Do not expose the product, accessories or battery to high temperatures, high humidity, or direct sunlight during operation, transportation, and storage.
- Depending on the conditions of use, the product may reach temperatures of 40 °C/104 °F or more. Do not touch the product for an extended period of time under these conditions. Extended contact under these conditions may cause low-temperature burns*.
 - * Low-temperature burns are burns that occur when the skin is in contact with objects of relatively low temperatures (40 °C or more/104 °F or more) for an extended period of time.
- Only use AC adaptors that meet the specifications provided. Using AC adaptors that do not meet these specifications may cause fire or electric shock.
- Do not swing the product around by the cable.
- The screen (touch screen) is made of glass. If the screen is cracked or damaged, do not touch it as it may cause injury.

Use and handling

Use the product and accessories according to the instructions in this manual. No authorization for the analysis or modification of the product, or the analysis and use of its circuit configurations, is provided.

Use in other countries

Depending on the country or region, there are limitations on the use of certain types of radio signals. In some cases, use of the product’s network features may lead to a fine or other penalty.

Moisture condensation

If the product is brought directly from a cold location to a warm one, moisture may condense inside the console, causing the product to malfunction. Should this occur, turn off the product and leave it until the moisture evaporates (this may take several hours). If the console still does not operate properly, please contact customer support.

LIMITED WARRANTY

Sony Interactive Entertainment LLC (“SIE LLC”) warrants to the original purchaser that this product shall be free from defects in material and workmanship for a period of one (1) year from the date of purchase. This warranty does not apply to any consumables (such as batteries). For defects in material or workmanship within the warranty period, upon showing a proof of purchase, SIE LLC agrees for a period of one (1) year to either repair or replace this product with a new or factory recertified product at SIE LLC’s option. For the purpose of this Limited Warranty, “factory recertified” means a product that has been returned to its original specifications. Visit playstation.com/help or call 1-800-345-7669 to receive a return authorization and shipping instructions. As the original purchaser, you will be responsible for inbound shipping costs and any packaging materials required. SIE LLC will then return the repaired or replaced product at no cost to you including return shipping. This warranty shall not be applicable and shall be void if the defect in the SIE LLC product has arisen through abuse, unreasonable use, mistreatment, neglect, or means other than from a defect in materials or workmanship.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AND NO OTHER REPRESENTATIONS OR CLAIMS OF ANY NATURE SHALL BE BINDING ON OR OBLIGATE SIE LLC. ANY IMPLIED WARRANTIES APPLICABLE TO THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE ONE (1) YEAR PERIOD DESCRIBED ABOVE. IN NO EVENT WILL SIE LLC BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM POSSESSION, USE OR MALFUNCTION OF THE SIE LLC PRODUCT. SOME STATES OR PROVINCES DO NOT ALLOW LIMITATION ON HOW LONG AN IMPLIED WARRANTY LASTS AND SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATIONS OF CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSION MAY NOT APPLY TO YOU.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.

This warranty is valid only in the United States and Canada.

Compliance information

FCC and ISED Canada Notice

The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power Wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure of low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research. This equipment has been tested and found to comply with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

NOTE:

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- You are cautioned that any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.
- For assistance with this product, visit playstation.com/help. The phone number in the supplier’s declaration of conformity is only for FCC electrical interference inquiries.

Supplier’s Declaration of Conformity

Trade Name : SONY
 Model No. : CFI-Y1001
 Responsible Party : Sony Electronics Inc.
 Address : 16535 Via Esprillo, San Diego, CA 92127 U.S.A.
 Telephone No. : 858-942-2230 (Only for FCC electrical interference inquiries)

This device complies with Part 15 of the FCC Rules and Innovation, Science and Economic Development Canada’s licence-exempt RSS(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC and ISED Certification

For more information about our FCC and ISED certifications, from your product’s home screen, go to **Quick Menu > Settings > Certification and Compliance**.

For customers in Canada

Operation in the 5150-5350 MHz band is restricted to indoor use only.

Further information

User’s guide

Find more detailed information about features and settings in the User’s Guide.



playstation.com/rp-usersguide/

Customer support website

Find online support information such as step-by-step troubleshooting and frequently asked questions by visiting playstation.com/help/.



